



Parts & Service

Sentry Washfountain


Discontinued Models Prior to
February 1, 2013




SN2003 (AST shown)



SN2004 (AST-F shown)



SN2005 (AST shown)



SN2023 (IR shown)

SN2003

36" Semi-Circular, Floor-Mounted

SN2004

54" Semi-Circular, Floor-Mounted

SN2023

36" Semi-Circular, Wall-Mounted

SN2024

54" Semi-Circular, Wall-Mounted

SN2005

36" Circular, Floor-Mounted

SN2008


54" Circular, Floor-Mounted

SN2013

54" Corner, Floor-Mounted


SN2033

54" Corner, Wall-Mounted



SN2013 (AST-4 shown)

SN2008 (AST shown)



SN2033 (IR shown)


Table of Contents

| | |
|---|----|
| How to Determine Drain Type..... | 2 |
| IR Assemblies, Troubleshooting and Wiring | 3 |
| Sentry Transformers..... | 13 |
| Supply Valves | 14 |
| AST4 Assemblies, Adjustments and Troubleshooting | 16 |
| Thermostatic Mixing Valve Troubleshooting | 23 |
| Manual Mixing and Control Valves..... | 25 |
| Check Valve Troubleshooting Instructions | 26 |
| Care and Cleaning of Stainless Steel Sentry Washfountains.... | 26 |
| Soap System | 27 |
| Pedestal Assembly..... | 29 |
| Backsplash Retrofit Kits..... | 30 |
| Shroud/Towel Dispensers | 31 |

How to Determine Drain Type




Parts may vary depending upon drain type. Identify your drain type before continuing.




TYPE A:

SUPPLIES BELOW
VENT OFF DRAIN
P-TRAP FURNISHED BY OTHERS




TYPE B:

SUPPLIES ABOVE
CENTRALLY-RISING VENT
P-TRAP FURNISHED



TYPE H:


SUPPLIES BELOW
CENTRALLY-RISING VENT
P-TRAP FURNISHED



TYPE O:

SUPPLIES ABOVE
VENT OFF DRAIN
P-TRAP FURNISHED BY OTHERS

Infrared (IR) — Sprayhead Assembly




Parts List — Infrared Sensor and Module

| Item | Part No. | Description | 54" Corner Qty. | 36" Semi Qty. | 54" Semi Qty. | 36" Circle Qty. | 54" Circle Qty. |
|------|-----------|-------------------------------------|-----------------|---------------|---------------|-----------------|-----------------|
| 1 | — | Shell | 1 | 1 | 1 | 1 | 1 |
| 2 | 269-982 | Lens (window) | 3 | 3 | 4 | 5 | 8 |
| 3 | 160-245 | Screw 10-24 x 1/2" | 6 | 6 | 8 | 10 | 16 |
| 4 | 142-002BT | Lock Washer | 6 | 6 | 8 | 10 | 16 |
| 5 | 142-002AV | Flat washer | 6 | 6 | 8 | 10 | 16 |
| 6 | 269-1184 | Sensor | 3 | 3 | 4 | 5 | 8 |
| 7 | 182-100 | Lens Support (Rubber Block) | 3 | 3 | 4 | 5 | 8 |
| 8 | 159-363 | Sensor Mounting Bracket | 3 | 3 | 4 | 5 | 8 |
| 9 | 161-082 | Nut - Extension 1/4"-20 x 5-1/8" | 2 | 2 | 2 | 2 | 2 |
| 10 | 269-621 | Terminal - female disconnect | 9 | 9 | 12 | 15 | 24 |
| 11 | S05-157 | Aerator Assembly (Std 0.5 GPM) | 3 | 3 | 4 | 5 | 8 |
| 11 | S05-172 | Aerator Assembly (Optional 1.5 GPM) | 3 | 3 | 4 | 5 | 8 |
| 12 | 110-115 | Nut - 1/2" - 14 | 3 | 3 | 4 | 5 | 8 |


Parts List — Aerator Assembly

| Item | Part No. | Description | S05-157 | S05-172 |
|------|----------|------------------------------------|---------|---------|
| | | | Qty | |
| 1 | S05-142A | Std. Aerator, 0.5 GPM | 1 | — |
| 1 | 153-397 | Extra Flow Aerator, 1.5 GPM | — | 1 |
| 2 | 153-402A | Adapter | 1 | 1 |
| 3 | 145-090 | 90° Connector 1/4" tube x 1/8" NPT | 1 | 1 |
| 4* | 130-141 | Spanner Wrench for Aerator | — | — |



*Spanner wrench not included in Assemblies

Infrared (IR) Part 1 — Solenoid Valve Assembly (24V Transformer) Prior to February 1, 2013




Parts List — Solenoid Valve Assembly

| Item | Part No. | Description | 54" | 36" | 54" | 36" | 54" |
|------|--------------|---|--------|------|------|--------|--------|
| | | | Corner | Semi | Semi | Circle | Circle |
| | | | Qty. | | | | |
| 1 | S27-102 | Stop/Check Valve | 2 | 2 | 2 | 2 | 2 |
| 2 | 269-1735 | Flex Hose | 2 | 2 | 2 | 2 | 2 |
| 3 | 140-928 | Bracket | 1 | 1 | 1 | — | — |
| * | 140-940 | Bracket | — | — | — | 1 | — |
| * | 140-941 | Bracket | — | — | — | — | 1 |
| 4 | 269-625 | Terminal Block | 1 | 1 | — | 2 | — |
| * | 269-647 | Terminal Block | — | — | 1 | — | 2 |
| 5 | P18-054 | Screw #10-24 x 3/8 | 2 | 2 | 2 | 2 | 2 |
| 6 | 160-447 | Screw #8-16 x 5/8 | 3 | 3 | 4 | 5 | 8 |
| 7 | S01-524 | Thermostatic Mixing Valve | 1 | 1 | 1 | 1 | 1 |
| 8 | S39-685 | Adapter (Optional Single Tempered Line) | 1 | 1 | 1 | 1 | 1 |
| 9 | S07-067 | Solenoid Valve - Closed Body (Black) | 1 | 1 | 1 | 1 | 1 |
| 10 | S07-067A | Solenoid Valve - Thru Body (Gray) | 2 | 2 | 3 | 4 | 7 |
| 11 | R68-600011-B | Tubing 1/4 OD Black | ** | ** | ** | ** | ** |
| 12 | R68-600011-G | Tubing 1/4 OD Green | ** | ** | ** | ** | ** |
| 13 | R68-600011-R | Tubing 1/4 OD Red | ** | ** | ** | ** | ** |
| * | R68-600011-Y | Tubing 1/4 OD Yellow | — | — | ** | ** | ** |
| * | R68-600011 | Tubing 1/4 OD Clear | — | — | — | ** | — |
| 14 | S45-2146 | Valve Assembly TMA 36S and 54K | 1 | 1 | — | — | — |
| * | S45-2148 | Valve Assembly TMA 54S | — | — | 1 | — | — |
| * | S45-2150 | Valve Assembly TMA 36C | — | — | — | 1 | — |
| * | S45-2152 | Valve Assembly TMA/IR 54C | — | — | — | — | 1 |

* Not Illustrated.

** Specify Length in feet.

Infrared (IR) Part 1 — Solenoid Valve Assembly (24V Transformer) Prior to May 2, 2005




Parts List — Solenoid Valve Assembly

| Item | Part No. | Description | 54" | 36" | 54" | 36" | 54" |
|------|------------|---|--------|------|------|--------|--------|
| | | | Corner | Semi | Semi | Circle | Circle |
| | | | Qty. | | | | |
| * | S08-061 | 3 Valve Assy. with Bracket | 1 | 1 | — | — | — |
| 1 | S08-062 | 4 Valve Assy. with Bracket | — | — | 1 | — | — |
| 1 | S08-358 | 5 Valve Assy. with Bracket | — | — | — | 1 | — |
| * | S08-359 | 8 Valve Assy. with Bracket | — | — | — | — | 1 |
| 2 | 160-245 | Screw for valve bracket | 2 | 2 | 2 | 2 | 2 |
| 3 | 140-917 | Valve Bracket - Semi & Corner | 1 | 1 | 1 | — | — |
| 3 | 140-918 | Valve Bracket - Circle | — | — | — | 1 | 1 |
| 4 | 160-329 | Screw 6-32 x 3/8" for terminal block | 2 | 2 | 2 | 4 | 4 |
| * | 161-069 | Lock Nut 6-32 for terminal block | 2 | 2 | 2 | 4 | 4 |
| 5 | 269-625 | Terminal Block - 3 Station | 1 | 1 | — | 2 | — |
| 5 | 269-647 | Terminal Block - 4 Station | — | — | 1 | — | 2 |
| * | S53-128 | Wire Assy. Black | 3 | 3 | 4 | 5 | 8 |
| * | S53-129 | Wire Assy. Red | 3 | 3 | 4 | 5 | 8 |
| * | 269-645 | Transformer 4RT Hard Wire 24V | 1 | 1 | 1 | — | — |
| * | 269-703 | Transformer 8RT Hardwire 24V - Circle | — | — | — | 1 | 1 |
| 6 | 269-1248 | U-Bolt | 1 | 1 | 1 | 1 | 1 |
| 7 | 161-026 | Nut 1/4"-20 | 2 | 2 | 2 | 2 | 2 |
| 8 | 269-1365 | Hose - Braided Flexible | 1 | 1 | 1 | 2 | 2 |
| 9 | R68-600011 | Tubing 1/4" OD (Specify Length in feet) | — | — | — | — | — |
| 10 | 269-1150 | Tee - 1/2" Brass | — | — | — | 1 | 1 |
| 11 | 113-006DH | 1/2" Close Nipple | — | — | — | 2 | 2 |
| 12 | 124-051 | Anti-Rotation Gasket | 1 | 1 | — | 2 | — |
| 12 | 124-052 | Anti-Rotation Gasket | — | — | 1 | — | 2 |

* Specify Length in feet.

Infrared (IR) Part 2 — Solenoid Valve Assembly (24V Transformer) Prior to February 1, 2013



Parts List — Solenoid Valve Assembly

| Item | Part No. | Description | Qty. |
|------|-----------|------------------------------------|------|
| 1 | 110-231 | Nut 1/4 Tube | 1 |
| 2 | 118-307 | Valve Body 1/4" Closed | 1 |
| 3 | 118-307A | Valve Body 1/4" Thru | 1 |
| 4 | 125-165 | O-Ring | 1 |
| 5 | 269-983 | Diaphragm | 1 |
| 6 | 269-577 | Armature | 1 |
| 7 | 269-578 | Spring | 1 |
| 8 | 269-1729 | Armature Housing | 1 |
| 9 | 269-1730 | Clamp | 1 |
| 10 | 160-447 | Screw #8-16 x 5/8 | 3 |
| 11 | 269-579 | Coil, Solenoid Valve | 1 |
| 12 | S07-067S | Solenoid Valve Closed Body (Black) | 1 |
| 13 | S07-067AS | Solenoid Valve Thru Body (Gray) | 1 |


Infrared (IR) Part 2 — Solenoid Valve Assembly (24V Transformer) S07-040 Individual (End), S07-041 Ganged (Prior to May 2, 2005)

S07-040 Solenoid Valve (Individual)

Used by itself, or is the last one (opposite end of the water inlet) in a group.

S07-041 Solenoid Valve (Ganged)

Used in a group, except the last in line. Body is drilled to allow water to pass thru into the next in line. This valve includes O-Ring 125-145 to seal to the next valve.



Parts List — Solenoid Valve Assembly

| Item | Part No. | Description | 54" | 36" | 54" | 36" | 54" |
|------|-----------|--------------------------------|--------|------|------|--------|--------|
| | | | Corner | Semi | Semi | Circle | Circle |
| | | | Qty. | | | | |
| 1-9 | S07-040 | Valve Individual | 1 | 1 | 1 | 2 | 2 |
| 1-10 | S07-041 | Valve Ganged | 2 | 2 | 3 | 3 | 6 |
| 1 | 160-066 | Screw 10-24 x 1/4 RD | 3 | 3 | 4 | 5 | 8 |
| 2 | 142-002AZ | Washer Stainless Steel | 3 | 3 | 4 | 5 | 8 |
| 3 | 269-579 | Coil - Solenoid Valve | 3 | 3 | 4 | 5 | 8 |
| 4 | 110-194 | Nut - Bonnet | 3 | 3 | 4 | 5 | 8 |
| 5 | 121-028 | Bonnet | 3 | 3 | 4 | 5 | 8 |
| 6 | 269-578 | Spring | 3 | 3 | 4 | 5 | 8 |
| 7 | 269-577 | Armature | 3 | 3 | 4 | 5 | 8 |
| 8 | 269-580 | Diaphragm | 3 | 3 | 4 | 5 | 8 |
| 9 | 118-237 | Valve Body Individual | 1 | 1 | 1 | 2 | 2 |
| 9 | 118-238 | Valve Body Ganged | 2 | 2 | 3 | 3 | 6 |
| 10 | 125-145 | O-Ring (for ganged valve body) | 2 | 2 | 3 | 3 | 6 |
| 11 | 110-224 | Nut | 3 | 3 | 4 | 5 | 8 |
| 12 | 129-049 | Tailpiece | 3 | 3 | 4 | 5 | 8 |
| 13 | 125-145 | O-Ring | 3 | 3 | 4 | 5 | 8 |
| 14 | 110-195 | Tailpiece Nut | 3 | 3 | 4 | 5 | 8 |
| 15 | 145-090 | Elbow, 1/8 NPTM x 1/4 Tube | 3 | 3 | 4 | 5 | 8 |

Infrared (IR) — Sensor and Solenoid Valve Troubleshooting

If a station is not functioning properly it is most likely either the solenoid valve or the sensor.

Troubleshooting multi station units is fairly easy, as you can swap parts (actually just by changing the wires) and use the process of elimination to figure out which of the 2 parts is causing the problem.


How the system operates:

1. The transformer sends 24 volts to the sensor.
2. The sensor acts only as a switch.
3. When hands go into the active field of the sensor, the sensor activates and sends a power signal on to the solenoid valve.
4. The power signal activates and opens the solenoid valve which allows the water to flow to the sprayhead. The solenoid valve stays open allowing water to flow as long as it is receiving a signal form the sensor (hands remain in the active field).
5. When hands are removed from the active field, the sensor turns off (note some models have a slight delay feature built-in.) and shuts off the power signal to the solenoid valve.


CAUTION: Turn off water supplies to unit before troubleshooting.

| Problem | Cause | Solution |
|--|---|--|
| An individual operating station fails to shut off and drips. | There is debris trapped between the diaphragm and the valve seat. | <p>Remove debris between diaphragm and the valve seat.</p> <ol style="list-style-type: none"> 1. Remove the three #8 Phillips-head screws that hold the solenoid valve assembly together. Be careful not to lose the armature or spring. 2. Remove the diaphragm. Remove any particles that have been trapped between the diaphragm and the valve seat. Rinse off the diaphragm and inspect for damage. Make sure the center orifice and both small side orifices are open. 3. Reassemble in reverse order, being careful not to overtighten the Phillips-head screws or you may crack the plastic valve body. Tighten until the armature plate makes contact with the plastic body. 4. Reconnect the wiring per the appropriate diagram on next 4 pages. |
| An individual operating station fails to turn on. | A failed coil for the valve or loose electrical connection to the terminal. | <p>Test the station to determine cause.</p> <ol style="list-style-type: none"> 1. Disconnect the wires from the coil of an adjacent valve. Disconnect the wires from the problem valve and reconnect to the adjacent valve. 2. Turn on electrical and water supplies to the unit. Pass your hand in front of the sensor of the problem station, and the adjacent station should turn on. <ol style="list-style-type: none"> a. If the adjacent station turns on and cycles normally, replace the coil on the problem valve. b. If the adjacent valve fails to turn on, inspect the wires from the sensor cable and do the following: <ul style="list-style-type: none"> • make sure there are no breaks and that the fully insulated disconnect terminals are firmly crimped in place; • turn off the electrical and water supplies; • reconnect to the adjacent valve and turn on the water supplies to the unit; • pass your hand in front of the sensor. If the station still fails to turn on, replace the sensor. |


Infrared (IR) SN2003, SN2023, SN2013, SN2033 Wiring Diagram Prior to February 1, 2013




Infrared (IR) SN2004, SN2024 Wiring Diagram Prior to February 1, 2013



Infrared (IR) SN2005 Wiring Diagram Prior to February 1, 2013



Infrared (IR) SN2008 Wiring Diagram Prior to February 1, 2013




Sentry Transformers


| Model | Description | Current | | Prior to May 2003 | |
|--------|-----------------------------------|-------------|------|-------------------|------|
| | | Part Number | Qty. | Part Number | Qty. |
| SN2003 | 36" Semi-Circular – Floor Mounted | S45-2045 | 1 | 269-645 | 1 |
| SN2004 | 54" Semi-Circular – Floor Mounted | S45-2045 | 1 | 269-645 | 1 |
| SN2023 | 36" Semi-Circular – Wall Mounted | S45-2045 | 1 | 269-645 | 1 |
| SN2024 | 54" Semi-Circular – Wall Mounted | S45-2045 | 1 | 269-645 | 1 |
| SN2005 | 36" Circular – Floor Mounted | S45-2045 | 2 | * 269-703 | 1 |
| SN2008 | 54" Circular – Floor Mounted | S45-2045 | 2 | * 269-703 | 1 |
| SN2013 | 54" Corner – Floor Mounted | S45-2045 | 1 | 269-645 | 1 |
| SN2033 | 54" Corner – Wall Mounted | S45-2045 | 1 | 269-645 | 1 |

* Available for service


Supply Valves




MMV — Manual Mixing
Complete Assy. as Shown - S67-203
(Prior to May 2, 2005)




TMA — Thermostatic Mixing
Complete Assy. as Shown - S67-571
(Prior to May 2, 2005)




TL — Tempered Line
Complete Assy. as Shown
S45-1966 (Prior to May 2, 2005)



PBV — Pressure Balancing
Complete Assy. as Shown - S67-516
(Prior to May 2, 2005)



TMA — Thermostatic Mixing
(Prior to February 1, 2013)



TL — Tempered Line
(Prior to February 1, 2013)

Parts List — Supply Valves

| Item | Part No. | Description | MMV | TMA | TL | PBV | TMA | TL | | |
|------|-----------|--|------------------------|-----|----|-----|-----|----|-------------------------|--|
| | | | (Prior to May 2, 2005) | | | | | | (prior to Feb. 1, 2013) | |
| | | | Qty. | | | | | | | |
| 1 | S01-038B | Mixing Valve - Manual | 1 | — | — | — | — | — | | |
| 2 | S01-116B | Mixing Valve - Thermostatic - Vernatherm | — | 1 | — | — | — | — | | |
| 4 | 269-653 | SS Flex Hose 1/2" NPT | 2 | 2 | 1 | 2 | — | — | | |
| 5 | S27-102 | Check Stop | 2 | 2 | 1 | 2 | 2 | 1 | | |
| *6 | 269-1188 | Filter Washer | 2 | 2 | 1 | 2 | — | — | | |
| 7 | 113-006DH | 1/2 x 1-1/2 Brass Pipe Nipple | — | — | — | 1 | — | — | | |
| 8 | S67-594 | Valve | — | — | — | 1 | — | — | | |
| 9 | 128-161 | Handle for valve | — | — | — | 1 | — | — | | |
| *10 | 160-214 | Screw for handle (PBV Valve only) | — | — | — | 1 | — | — | | |
| 11 | 169-168 | Pipe Plug for bottom of valve | — | — | — | 1 | — | — | | |
| 12 | S39-685 | Adapter (Optional Single Tempered Line) | — | — | — | — | — | 1 | | |
| 13 | 269-1735 | Flex Hose | — | — | — | — | 2 | 1 | | |
| 14 | S01-524 | Thermostatic Mixing Valve | — | — | — | — | 1 | — | | |


* Not Illustrated.

Air Metering Valve (AST4) — Hand Pushbutton and Sprayhead (Prior to May 2, 2005)

Pushbutton Replacement

CAUTION: Turn off water supplies before replacing the pushbutton.

1. Remove the sprayhead cover by removing the two screws holding the cover to the sprayhead module.
2. Inside sprayhead, unscrew the two screws that hold the actuator body to the bracket being careful of the spring that will release.
3. Unscrew and remove the coupling if necessary.
4. Unscrew and remove the brass nut if necessary. This will allow the pushbutton assembly to be removed.
5. Carefully take apart the assembly and replace the parts as needed.
6. After replacement is complete, reassemble the pushbutton and sprayhead as shown.



Parts List — Pushbutton


| Item | Part No. | Description | 54" Corner Qty. | 36" Semi Qty. | 54" Semi Qty. | 36" Circle Qty. | 54" Circle Qty. |
|------|------------|---|-----------------|---------------|---------------|-----------------|-----------------|
| 1 | — | Shell | 1 | 1 | 1 | 1 | 1 |
| 2 | S08-324 | Pushbutton Assy. (includes items 3–5) | 3 | 3 | 4 | 5 | 8 |
| 3 | 128-090 | Pushbutton Only | 3 | 3 | 4 | 5 | 8 |
| 4 | 179-102 | Guide for Pushbutton | 3 | 3 | 4 | 5 | 8 |
| 5 | 147-033 | Screw for Pushbutton | 3 | 3 | 4 | 5 | 8 |
| 6 | 140-743 | Bracket - Actuator | 3 | 3 | 4 | 5 | 8 |
| 7 | 110-115 | Nut 1/2"-14 | 3 | 3 | 4 | 5 | 8 |
| ●8 | 169-890 | Connector 1/8" tube x 10-32 Thd. | 3 | 3 | 4 | 5 | 8 |
| ●9 | 269-1186 | "L" Fitting Adjustable | 3 | 3 | 4 | 5 | 8 |
| ●10 | 118-279 | Actuator Body | 3 | 3 | 4 | 5 | 8 |
| ●11 | 135-065 | Spring | 3 | 3 | 4 | 5 | 8 |
| ●12 | 125-099 | U-Cup for piston | 3 | 3 | 4 | 5 | 8 |
| ●13 | 119-227 | Piston | 3 | 3 | 4 | 5 | 8 |
| 14 | 160-165 | Screw - Body mounting | 6 | 6 | 8 | 10 | 16 |
| 15 | R68-600008 | Tubing 1/8" OD (specify length in feet) | — | — | — | — | — |
| *16 | S05-157 | Aerator Assembly (Std 0.5 GPM) | 3 | 3 | 4 | 5 | 8 |
| *16 | S05-172 | Aerator Assembly (Optional 1.5 GPM) | 3 | 3 | 4 | 5 | 8 |
| 17 | 110-115 | Nut - 1/2" - 14 | 3 | 3 | 4 | 5 | 8 |
| 18 | 161-082 | Nut - Extension 1/4"-20 x 5-1/8" | 2 | 2 | 2 | 2 | 2 |
| 19 | 130-141 | Spanner Wrench for Aerators | 1 | 1 | 1 | 1 | 1 |
| 20 | R68-600011 | Tubing 1/4" OD (specify length in feet) | — | — | — | — | — |
| 21 | 130-023 | Spanner Wrench for Pushbuttons | 1 | 1 | 1 | 1 | 1 |

● Prepack S65-168A * See page 3 for additional information.


Air Metering Valve (AST4-F) — Foot Pushbutton and Actuator (Prior to May 2, 2005)

Parts List — Aerator Assembly


| Item | Part No. | Description | S05-157 | S05-172 |
|------|----------|------------------------------------|---------|---------|
| | | | Qty. | |
| 1 | S05-142A | Standard Aerator, 0.5 GPM | 1 | — |
| 1 | 153-397 | Extra Flor Aerator, 1.5 GPM | — | 1 |
| 2 | 153-402A | Adapter | 1 | 1 |
| 3 | 145-090 | 90° Connector 1/4" tube x 1/8" NPT | 1 | 1 |
| 4* | 130-141 | Spanner Wrench for Aerator | — | — |



Foot Pushbutton Assembly
S45-1543



Actuator Assembly S08-288




Parts List — Foot Pushbutton Assembly (S45-1543)

| Item | Part No. | Description | Qty. |
|------|----------|----------------------|------|
| 1 | S08-288 | Actuator Assy. | 1 |
| 2 | 140-604 | Bracket | 1 |
| 3 | 150-198 | Escutcheon | 1 |
| 4 | 128-090 | Pushbutton | 1 |
| 5 | 179-071 | Pushbutton Guide | 1 |
| 6 | 110-115 | Nut 1/2"-14 | 1 |
| 7 | 119-132 | Plunger | 1 |
| 8 | 160-245 | Screw for escutcheon | 2 |

Parts List — Actuator Assembly (S08-288)

| Item | Part No. | Description | Qty. |
|------|-----------|---------------------------------------|------|
| 1 | 160-276 | Screw 8-32 x 3/4" | 4 |
| 2 | 140-493 | Mounting Plate | 1 |
| 3 | 269-612 | Diaphragm | 1 |
| 4 | 269-613 | Back Plate | 1 |
| 5 | 161-062 | Nut 8-32 | 4 |
| 6 | 269-1186 | Fitting adjustable "L" | 1 |
| 7 | 142-002CR | Washer #8 lock | 4 |
| 8 | 125-001CZ | O-Ring | 1 |
| 9 | 169-890 | Fitting - tube connector 10-32 x 1/8" | 1 |

Air Metering Valve (AST4) Part 1 — Assembly and Components (Prior to February 1, 2013)



3 Valve Assembly Shown


Parts List — Air Metering Valve Assembly

| Item | Part No. | Description | 54" | 36" | 54" | 36" | 54" |
|------|--------------|---|--------|------|------|--------|--------|
| | | | Corner | Semi | Semi | Circle | Circle |
| | | | Qty. | | | | |
| 1 | S27-102 | Stop/Check Valve | 2 | 2 | 2 | 2 | 2 |
| 2 | 269-1735 | Flex Hose | 2 | 2 | 2 | 2 | 2 |
| 3 | 140-928 | Bracket | 1 | 1 | 1 | — | — |
| * | 140-940 | Bracket | — | — | — | 1 | — |
| * | 140-941 | Bracket | — | — | — | — | 1 |
| 4 | P18-054 | Screw #10-24 x 3/8 | 2 | 2 | 2 | 2 | 2 |
| 5 | 160-447 | Screw #8-16 x 5/8 | 3 | 3 | 4 | 5 | 8 |
| 6 | S01-524 | Thermostatic Mixing Valve | 1 | 1 | 1 | 1 | 1 |
| 7 | S39-685 | Adapter (Optional Single Tempered Line) | 1 | 1 | 1 | 1 | 1 |
| 8 | S07-077A | AST4 Valve, through body (Gray) | 2 | 2 | 3 | 4 | 7 |
| 9 | S07-077 | AST4 Valve, closed body (Black) | 1 | 1 | 1 | 1 | 1 |
| 10 | R68-600011-B | Tubing 1/4 OD Black | ** | ** | ** | ** | ** |
| 11 | R68-600011-G | Tubing 1/4 OD Green | ** | ** | ** | ** | ** |
| 12 | R68-600011-R | Tubing 1/4 OD Red | ** | ** | ** | ** | ** |
| * | R68-600011-Y | Tubing 1/4 OD Yellow | — | — | ** | ** | ** |
| * | R68-600011 | Tubing 1/4 OD Clear | — | — | — | ** | — |
| 13 | R68-600008-B | Tubing 1/8 OD Black | ** | ** | ** | ** | ** |
| 14 | R68-600008-G | Tubing 1/8 OD Green | ** | ** | ** | ** | ** |
| 15 | R68-600008-R | Tubing 1/8 OD Red | ** | ** | ** | ** | ** |
| * | R68-600008-Y | Tubing 1/8 OD Yellow | — | — | ** | ** | ** |
| 16 | S08-443TMA | Valve Assembly AST | 1 | 1 | — | — | — |
| * | S08-444TMA | Valve Assembly AST4 | — | — | 1 | — | — |
| * | S08-445TMA | Valve Assembly AST4 | — | — | — | 1 | — |
| * | S08-448TMA | Valve Assembly AST4 | — | — | — | — | 1 |

* Not Illustrated.

** Specify Length in feet.



Air Metering Valve (AST) Part 1 — Assembly and Components (Prior to May 2, 2013)



Parts List — Air Metering Valve Assembly

| Item | Part No. | Description | 54" | 36" | 54" | 36" | 54" |
|------|------------|---|--------|------|------|--------|--------|
| | | | Corner | Semi | Semi | Circle | Circle |
| | | | Qty. | | | | |
| 1 | S67-205 | Air Valve Assy. - Hand Control | 1 | 1 | — | — | — |
| 1 | S67-206 | Air Valve Assy. - Foot Control | 1 | 1 | — | — | — |
| 1 | S67-207 | Air Valve Assy. - Hand Control | — | — | 1 | — | — |
| 1 | S67-208 | Air Valve Assy. - Foot Control | — | — | 1 | — | — |
| 1 | S67-209 | Air Valve Assy. - Hand Control | — | — | — | 1 | — |
| 1 | S67-210 | Air Valve Assy. - Foot Control | — | — | — | 1 | — |
| 1 | S67-211 | Air Valve Assy. - Hand Control | — | — | — | — | 1 |
| 1 | S67-212 | Air Valve Assy. - Foot Control | — | — | — | — | 1 |
| 2 | 113-006DH | Close Nipple 1/2" | 2 | 2 | 3 | 4 | 7 |
| 3 | 169-168 | Pipe Plug 1/2" | 1 | 1 | 1 | 1 | 1 |
| 4 | 145-097 | Connector 1/4" tube x 3/8" NPT | 3 | 3 | 4 | 5 | 8 |
| 5 | S07-058 | Air Metering Valve - Hand Control | 1 | 1 | 1 | 1 | 1 |
| 5 | S07-059 | Air Metering Valve - Foot Control | 1 | 1 | 1 | 1 | 1 |
| 6 | R68-600011 | Tubing 1/4" OD (specify length in feet) | — | — | — | — | — |
| 7 | R68-600008 | Tubing 1/8" OD (specify length in feet) | — | — | — | — | — |
| 8 | 269-1248 | U-Bolt | — | 1 | 1 | — | — |
| 9 | 161-026 | Nut 1/4" - 20 | 1 | 2 | 2 | — | — |
| 10 | 110-115 | Nut - 1/2" - 14 | 2 | — | — | 1 | 1 |
| 11 | 153-409 | Plug | — | — | — | 1 | 1 |

Air Metering Valve (AST4) Part 2 — Assembly and Components (Prior to February 1, 2013)




Parts List - AST4 Valve

| Item | Description | AST4 Valve S65-260 | Repair Kit (Upper) S65-261 | Repair Kit (Lower) S65-262 | AST4 Foot Valve S65-280 | Repair Kit Foot (Upper) S65-281 |
|------|-----------------------------|-----------------------|----------------------------------|----------------------------------|-------------------------------|---------------------------------------|
| 1 | Diaphragm | 1 | — | 1 | 1 | — |
| 2 | Armature | 1 | — | 1 | 1 | — |
| 3 | Spring | 1 | — | 1 | 1 | — |
| 4 | AST4 Valve Upper Body | 1 | — | — | 1 | — |
| 5 | Magnet / Diaphragm Assembly | 1 | 1 | — | 1 | 1 |
| 6 | AST4 Valve Cover | 1 | 1 | — | — | — |
| 7 | AST4 Valve Clamp Nut | 1 | 1 | — | 1 | 1 |
| 8 | AST4 Valve Timer Assembly | 1 | — | — | — | — |
| 9 | O-Ring (-012) | 1 | — | — | — | — |
| 10 | AST4 Valve Timer Cover | 1 | — | — | — | — |
| 11 | Screw, #8 x 7/8" | 3 | — | — | 3 | — |
| 12 | Compression Nut, 1/8" Tube | 1 | 1 | — | — | — |
| 13 | AST4 Valve Cover Foot | — | — | — | 1 | 1 |
| 14 | Tube Connector | — | — | — | 1 | 1 |
| 15 | Compression Spring, AST4 | 1 | 1 | — | 1 | 1 |

Air Metering Valve (AST) Part 2 — Assembly and Components (Prior to May 2, 2005)

S07-058 – Air Valve - Hand Control (shown)
S07-059 – Air Valve - Foot Control




Parts List - AST Valve


| Item | Part No. | Description | Qty. |
|------|-----------|---|------|
| 1 | S07-058 | Air Valve - Hand Control | 1 |
| 1 | S07-059 | Air Valve - Foot Control (does not use timer assy.) | 1 |
| 2 | 118-183 | Valve Body lower | 1 |
| 3 | 117-036 | Valve Seat | 1 |
| 4 | 269-665 | Rubber Diaphragm | 1 |
| 5 | 269-664 | Seat Guide | 1 |
| 6 | 179-082 | Armature w/ Grommet | 1 |
| 7 | 135-053 | Spring | 1 |
| 8 | S65-110 | Repair Kit, Air Valve - Universal (Includes Items 4-7) | — |
| 9 | S73-054A | Repair Kit, Air Valve - Hand (Includes Items 4-12) | — |
| 9 | S73-054B | Repair Kit, Air Valve - Foot (Includes Items 4-7, & 12) | — |
| 10 | S27-254 | Timer Assy. (Not used in S07-059) | 1 |
| 11 | 269-656 | Cover for timer assy. (Not used in S07-059) | 1 |
| 12 | 169-890 | Tube Connector 1/8" straight | 1 |
| 13 | 142-002CR | Lockwasher #8 | 4 |
| 14 | 160-313 | Screw | 4 |

Air Metering Valve Maintenance (Prior to May 2, 2005)

Adjust Air Valve Meter Time


 The air valve timer is located next to the tube connector on the air valve body. The timer is capped with a filter to prevent build-up on the timer. The air valve timing can be adjusted from 0 to 45 seconds.

1. Remove filter cap and use a screwdriver to tighten or loosen the timer. Turning the timer clockwise increases the time; turning the timer counterclockwise decreases the time.
2. Continue to adjust until the timer is set at desired length.
3. Replace filter cap over the timer.




Tube Connection Leaks

1. Push in the white manual release button while pulling the tube out to disconnect the tube at the connector. No tools are needed.
2. To correct a leak, press tubing firmly into the connector and make sure it is seated.
3. If leak persists, remove tubing from the fitting and trim the tubing end square with a razor-sharp knife. If leak continues, replace the fitting or contact your Bradley representative for assistance.




Control Valve Illustrations

Hand Control Only




Foot Control Only



Troubleshooting Air Metering Valve (AST4)

CAUTION: Turn off water supplies to unit before troubleshooting.

| Problem | Cause | Solution |
|---|---|---|
| Water is dripping from the aerators | Debris on valve seat or orifices | Clean and inspect valve seat (Air Metering Valve Assembly and Components) 1. Remove screws and disassemble metering valve. 2. Clean valve seat and inspect for deep gouges or scratches. Replace if necessary. 3. Remove all debris that may be clogging center hole of the plastic diaphragm assembly and offcenter hole in the rubber diaphragm. |
| Valve will not shut off | Timing mechanism is clogged | Clean timing mechanism 1. Remove plastic sleeve from timer assembly. 2. Blow water and debris from timing mechanism if compressed air is available. 3. Turn the adjusting screw in all the way but do not force screw. 4. Turn adjusting screw out to desired cycle time. |
| Valve will not turn on | Water is not being supplied to unit | Open all stops on the valve assembly. |
| Timing cannot be adjusted for more than five seconds | There is an air leak | Check assembly 1. Check all tubing and fittings for proper assembly. 2. Tighten all screws which hold valve together. |
| Pushbutton does not work properly | Air volume may not be sufficient to operate valve | Check all fittings for air leaks |
| Valve cycles properly, but water does not form streams and drips from aerator | Tube connector is not seated properly | Inspect and clean air flow control assembly 1. Replace 1/4" tubing as follows: cut 1/4" from the end of the tube to make sure the end is square, then insert into tube connector fitting. |



Thermostatic Mixing Valve Troubleshooting (Prior to February 1, 2013)

Before attempting to troubleshoot the valve or disassemble the components, check for the following conditions:

- If stop valves are used, make sure that they are fully open.
- Make sure that the hot and cold inlet pipes are connected properly, and that there are no cross-connections or leaking stop valves.
- Check the hot water heater output to make sure that it is at least 20° F above the set temperature.



Be sure to close the appropriate shut-off valves prior to disassembly of the valve and reopen the valves after inspection and repair is complete.

| Problem | Cause | Solution |
|--|---|--|
| External leaks. | Damaged O-rings. | Replace O-rings where necessary. For replacement of the O-rings, contact your Bradley representative and ask for Repair Kit (part number S65-259). |
| Improper water temperature or temperature fluctuation. | Thermostat is slowly failing or not working at all. | <p>Check the thermostat for proper operation.</p> <ol style="list-style-type: none"> 1. At room temperature (80° F or less) remove cap and thermostat. 2. Place thermostat into container with 115° F water. The pushrod should pop out of the thermostat approximately 1/10". 3. If thermostat pushrod does not pop out, the thermostat must be replaced. Contact your Bradley representative and ask for Repair Kit (part number S65-259). |
| | Valve temperature is not properly set. | Adjust the temperature. |
| Limited water flow. | Dirt and debris have built up in the valve or strainer. | <p>Check the valve's piston for free and smooth movement,</p> <ol style="list-style-type: none"> 1. Remove the valve's cap and thermostat 2. Push down on the piston with your finger (the piston should move freely). If the movement is not as it should be, the piston needs to be cleaned. Follow the method outlined below for cleaning the piston and valve body: <ul style="list-style-type: none"> • Remove the thermostat. • Lift the piston out with a needle-nose pliers and remove the spring. • Any cleaner suitable for brass and stainless steel may be used (if cleaning with suitable cleaner is not sufficient to remove debris, a 400-grit sandpaper may be used to polish and hone the piston and valve body). • Snap spring into piston (will detent) and reassemble into the valve body. • Retest the piston. 3. If, after a thorough cleaning, the piston does not move freely, the piston must be replaced. Contact your Bradley representative and ask for Repair Kit (part number S65-259). |

Vernatherm Thermostatic Mixing Valve S01-116B Maintenance and Troubleshooting (Prior to May 2, 2005)

* Repair kit S45-049 is pre-packaged and includes O-Ring, Flip Ring, Power Element and Spring.


Maintenance Instructions

1. Disassemble the Vernatherm™ Valve as shown, being careful not to damage the power element. Replace the element, if necessary.
2. If necessary, remove the old flip ring and replace with a new ring.



An old or worn flip ring may cause temperature fluctuation and/or water chatter.

3. Reassemble the power element and valve body. Apply grease to the main valve slide and gently ease into position, rotating so that grease is applied to the flip ring. Do not force the slide as this may push the flip ring from its position. To test, rotate the slide; a slight drag should be felt when correctly installed.
4. Reassemble the valve.



Service Suggestions

When servicing the Vernatherm™ valve, make sure it is installed in the correct position. The most common error that occurs is when the valve is installed in the reversed position, that is, the hot line is connected to the cold line and the cold is connected to the hot.




A red ring is painted on the hot side of the valve.

The table below lists conditions that occur when the valve is installed correctly, and when it is in the reversed position.

| Valve Position is | If | | Then Valve Delivers |
|-------------------|------------|-------------|--------------------------------|
| | Hot Supply | Cold Supply | |
| Correct | Hot | Cold | Mixed 107° |
| Correct | Hot | No Water | Valve shuts off or drips |
| Correct | No Water | Cold | Valve shuts off or drips |
| Correct | Hot | Hot | Hot |
| Correct | Cold | Cold | Cold |
| Reversed | Hot | Cold | Cold/below 107° Hot/above 107° |
| Reversed | Hot | No Water | Hot |
| Reversed | No Water | Cold | Cold |
| Reversed | Hot | Hot | Hot |
| Reversed | Cold | Cold | Cold |

Manual Mixing Valve — S01-038B (Prior to May 2, 2005)

| Item | Part No. | Description | Qty. |
|------|-----------|---------------------------|------|
| 1 | 118-034B | Mixing Valve Body - Brass | 1 |
| 2 | 124-001BD | Fiber Washer | 1 |
| 3 | 125-001BC | O-Ring | 1 |
| 4 | 119-059 | Mixing Valve Core | 1 |
| 5 | 152-038 | Roll Pin | 1 |
| 6 | 121-016 | Bonnet - Brass | 1 |
| 7 | 160-197 | Screw - Brass | 1 |
| — | S45-197 | Repair Kit (Items 2-7) | — |



Check Valve Troubleshooting Instructions

| Problem | Solution |
|---|---|
| If water just dribbles or does not flow from sprayhead. | <ol style="list-style-type: none"> 1. Close stop/check valves that supply water to the washfountain. 2. Inspect stop/check valves for proper installation. 3. Remove flexible hoses at stop/check valves and clean the strainers if necessary. |
| If water sprayhead delivers all hot or cold water. | <ol style="list-style-type: none"> 1. Close stop/check valves that supply water to the washfountain. 2. Inspect stop/check valves for proper installation. 3. Remove flexible hoses at stop/check valves and clean the strainers if necessary. 4. Inspect mixing valve for proper installation. <ul style="list-style-type: none"> • Hot inlet is marked with an "H". |

Care and Cleaning of Stainless Steel Sentry Washfountains

Stainless steel is extremely durable, and maintenance is simple and inexpensive. Proper care, particularly under corrosive conditions, is essential. Follow the cleaning instructions listed below:

- Ordinary deposits of dirt and grease are quickly removed with soap and water. Whenever possible, the metal should be thoroughly rinsed and dried after washing. To remove tightly adhering deposits, use stainless steel polishing powder. In all cases, rub in the direction of the stainless steel grain.



Never use ordinary steel wool or steel brushes on stainless steel. Always use stainless steel wool or stainless steel brushes.


- Avoid prolonged contact with chlorides, bromides, thiocyanates, and iodides on stainless steel equipment, especially if acid conditions exist.
- Do not permit salty solutions to evaporate and dry on stainless steel.
- The appearance of rust streaks on stainless steel leads to the belief that the stainless steel is rusting. Look for the actual source of the rust in some iron or steel particles which may be touching, but not actually a part of the stainless steel structure. *NOTE: Strongly acidic or caustic cleaners may attack the steel causing a reddish film to appear. The use of these cleaners should be avoided.*

Soap System

Parts List — Sprayhead Cover and Soap System


| Item | Part No. | Description | Qty. |
|------|----------|--|--------|
| 1 | 160-154 | Screw for cover | 2 |
| 2 | — | Cover - Call for part number | 1 |
| 3 | 133-134 | Tank (1 per semi, 2 per circle) | 1 or 2 |
| 4 | 161-082 | Nut - Extension 1/4"-20 x 5-1/8" for cover | 2 |
| * | 153-330 | Plug Button - to plug soap valve holes | 2 or 4 |

* Not illustrated.



Parts List — Soap Valve S09-007

| Item | Part No. | Description | Qty. |
|------|-----------|--|------|
| 1 | S09-007 | Soap Valve - Valve only (Items 2-6) | 1 |
| 1 | S09-007S | Soap Valve - Valve w/ Attaching Hardware (Items 2-9) | 1 |
| 2 | 118-025 | Valve Body | 1 |
| 3 | 110-007 | Packing Nut | 1 |
| 4 | 135-001L | Spring | 1 |
| 5 | 125-001BU | Washer - Rubber | 1 |
| 6 | 119-028 | Plunger | 1 |
| 7 | 161-014 | Nut | 1 |
| 8 | 124-001BV | Washer - Fiber | 1 |
| 9 | 142-002AH | Washer - Stainless Steel | 1 |



This soap valve delivers soap with each upward stroke. This soap valve is not suited for lotion soaps.

Lotion soap will clog liquid soap valves.

Soap System

Soap Recommendations

Quality soap dispensers require good quality soap and periodic maintenance to properly operate. Bradley soap dispensers will provide dependable, consistent operation over the long term when soap with reasonable viscosity and pH levels are used and when a minimal amount of periodic maintenance is performed on the valves.

Soap thickness is determined by a measurement called viscosity. Soap viscosity should be between 100 cps (centerpoise) and 2500 cps for all Bradley soap dispensers. Thinner soaps are perceived by the users as being "watered down" so users tend to take more than they need, resulting in waste. **Thick soaps flow slower and inhibit the "flushing" action of the valves, which allows the soap to congeal in the valve and cause clogs.**

The pH (acid) level of the soap should be in the range of 6.5 to 8.5. More acidic soaps (pH levels lower than 6.5) will corrode metal parts (even stainless steel!!) and degrade rubber and plastic components. They will also cause skin irritation. **Most inexpensive soaps (typically the pink lotion type) fall into this acidic category and will eventually cause valve failure and metal corrosion.** Base soaps (pH levels higher than 8.5) will cause swelling or degradation of rubber and plastic parts and skin irritation.

Generally, any quality soap meeting the viscosity and pH guidelines above will work well with Bradley soap dispensers. PCMX or Isopropanol based antibacterial soaps (within viscosity and pH limits) will also work with Bradley dispensers. Soaps satisfying these basic guidelines will provide consistent flow and reduce clogs.

Most soap dispenser problems are caused by soap that is too thick or corrosive, or by a lack of maintenance. Many soaps come in concentrate form which must be diluted with water. Often, the soap is improperly diluted or used straight out of the bottle, which causes clogging and valve failure. If proper soap is being used, valves that have never been cleaned are usually the source of dispensing problems. Bradley has entered into an agreement with Champion Brand Products to provide additional customer service for purchasers of our dispensers regarding soap issues. They are very helpful and can get to the bottom of almost any soap dispenser related problem. They also sell an excellent "Bradley approved" soap. Please see **Soap Instruction Sheet 215-1286** for details about soap valve cleaning or how to contact Champion. With proper maintenance and soap, Bradley dispensers will provide long term, trouble free operation.

Soap Dispenser Maintenance Instructions for Sentry Washfountains


Bradley soap dispensers will provide dependable, consistent operation over the long term when the proper soap is used and when a minimal amount of periodic maintenance is performed on the valves. Valves must be maintained (cleaned) to function properly.

To ensure proper operation of your soap dispenser, follow these instructions:

- Once per month, remove the cap from the soap tank and insert the draw tube (below the cap) into hot water and soak it for 30 minutes.
- Push valve at least 20 times while it is soaking.
- Flush soap reservoir with hot water while valve is soaking.

In cases of extreme clogging, the valve should be disassembled and the parts should be soaked in hot water or cleaning solution to restore proper functioning. Soap dispensers that will not be used for extended periods of time (schools during summer break, etc.) should be drained, cleaned and left empty until put back into service. Soap left on the outside of dispensers can cause discoloration and corrosion of the reservoir (even on stainless steel units). All soap should be wiped or scrubbed off daily, then the outside of the dispenser should be rinsed with clear water and dried with a soft cloth.

Pedestal Assembly — Access Panels, Bowl Hardware, Drain Parts



Parts List — Access Panel

| Model No. | Part No. | Height | Qty. |
|-----------|----------|---------|------|
| SN2003 | 186-1207 | STD/JUV | 1 |
| SN2004 | 186-1207 | STD/JUV | 1 |
| SN2005 | 186-1202 | STD/JUV | 2 |
| SN2008 | 186-1202 | STD/JUV | 2 |
| SN2013 | 186-743 | JUV | 2 |
| SN2013 | 186-669 | STD | 2 |
| SN2023 | 186-1207 | WALL | 1 |
| SN2024 | 186-1207 | WALL | 1 |
| SN2033 | 186-757 | WALL | 2 |

Access Panel Screws, #10-24 x 1/2" long (P/N 160-120)

Parts List— Drain

| Item | Part No. | Description | Qty. |
|------|----------|---------------------|------|
| 1 | S29-021 | P-Trap 1-1/2" | 1 |
| 2 | 113-731 | Close Nipple 1-1/2" | 1 |
| 3 | 269-557 | Tee-Y 1-1/2" | 1 |
| 4 | S29-083 | Tailpiece 1-1/2" | 1 |
| 5 | 112-028 | Drain Spud | 1 |
| 6 | 173-002 | Strainer | 1 |
| 7 | 160-042 | Screw for strainer | 2 |
| 8 | 142-063 | Washer for spud | 1 |
| 9 | 161-148 | Nut for spud | 1 |


Parts List— Bowl Hardware

| Item | Part No. | Description | Qty. |
|------|-----------|------------------|--------|
| 10 | 142-002AT | Flat Washer 1/4" | 3 or 4 |
| 11 | 142-002BS | Lock Washer 1/4" | 3 or 4 |
| 12 | 161-026 | Hex Nut 1/4"-20 | 3 or 4 |

Backsplash Retrofit Kits — 36" Semi and 54" Semi

Installation


1. Loosen the bowl anchors.
2. Slide the backsplash between the wall and bowl making sure the slots on the backsplash are aligned with the bolts.
3. Caulk the lower edge of the backsplash where it meets the bowl.
4. Tighten the bowl anchors.



Parts List— Bowl Hardware

| Part No. | Description | Qty. |
|----------|-----------------|------|
| S65-237 | 36" Semi-Circle | 1 |
| S65-238 | 54" Semi-Circle | 1 |

Shrouds/Towel Dispensers



Parts List — Shroud Installations

| Item | Part No. | Description | Corner & Semi Qty. | Circle Qty. |
|------|----------|---|--------------------|-------------|
| 1 | S70-095 | Mounting Bracket - for shroud mtg. | 2 | 2 |
| 2 | S78-002 | Towel Dispenser - Single fold | 2 | 3 |
| 2 | S78-001 | Towel Dispenser - Multi fold | 2 | 3 |
| * | S45-183 | Prepack - For shroud mounting | — | — |
| 3 | 160-169 | Screw - Bracket to shroud (included in S45-183) | 6 | 6 |
| 4 | 160-138 | Screw - Shroud to cover | 3 | 3 |
| 5 | S57-040 | Slip Ring for shroud | 1 | 1 |
| 6 | — | Shroud - Call for part number | 1 | 1 |
| 7 | S10-009 | Soap Filler Cap | 2 | 2 |
| 8 | 107-445 | Sprayhead Cover for Shroud | 1 | 1 |

* Not illustrated.

Parts List — Pipe Installations

| Item | Part No. | Description | Corner & Semi Qty. | Circle Qty. |
|------|----------|--|--------------------|-------------|
| 1 | S70-123 | Mounting Bracket - for 1-1/2" pipe mtg. | 2 | 2 |
| 2 | S78-002 | Towel Dispenser - Single fold | 2 | 3 |
| 2 | S78-001 | Towel Dispenser - Multi fold | 2 | 3 |
| * | S45-205 | Prepack - For 1-1/2" pipe mounting | — | — |
| 3 | 159-020 | Tie Bar-Tie Pipe (included in S45-205) | 2 | 2 |
| 4 | 160-208 | Screw - Tie bar to pipe (included in S45-205) | 6 | 6 |
| 5 | 160-111 | Screw - Bracket to tie bar (included in S45-205) | 4 | 4 |
| 6 | 169-986A | Pipe Cap (included in S45-205) | 1 | 1 |
| 7 | 113-170 | Spacer Sleeve - for 1-1/2" pipe mtg. | 1 | 1 |

* Not illustrated.