

Bradrol Valves

How they Work:

Counter-clockwise rotation of the handle and cam causes the rubber sleeve & insert to contract which uncovers the ports in the cartridge allowing water to flow through the valve body.

Troubleshooting		
<i>Problem</i> -----	<i>Cause</i> -----	<i>Solution</i>
Water drips from shower head.	Mineral or foreign material build up on cartridge ports	Clean or replace cartridge and sleeve & insert
Water will not shut off	Sleeve & insert split	Replace sleeve & insert