

Faucet Accessories


Vernatherm™

Thermostatic Mixing Valve Assembly


Models TMAR (Recessed), and TMAS (Surface Mounted)

Models TMAR (Recessed) and TMAS (Surface Mounted)


- Includes 18-gauge stainless steel cabinet, TMA Vernatherm valve with stop-strainer-check valves
- Includes all piping for inside cabinet 1/2" IPS inlet and outlet connections
- 16-gauge stainless steel door with key lock



TMAR Recessed-Mounting Cabinet



TMAS Surface-Mounting Cabinet



DISCONTINUED

Document No. 3090


This information is subject to change without formal notice.
0799RSSAW (3 Pages Total)



P.O. Box 309, Menomonee Falls, WI 53052-0309
Phone 1-800-BRADLEY FAX 262-251-5817
<http://www.bradleycorp.com>
Technical Information Fax Service: 1-800-BRADFAX

Faucet Accessories

Vernatherm™ Thermostatic Mixing Valve Assembly with Solenoid Valves




* NOTE: All boxes with solenoid valves must be mounted below the plane the faucets are mounted on.

Bradley Corporation reserves the right to make changes in design and material without formal notice and without incurring obligation. Verify all rough-in dimensions prior to installation.

Faucet Accessories

Vernatherm™ Thermostatic Mixing Valve Assembly with Solenoid Valves



* NOTE: All boxes with solenoid valves must be mounted below the plane the faucets are mounted on.

Document No. 3090

This information is subject to change without formal notice.
0799RSSAW (3 Pages Total)

Bradley 

P.O. Box 309, Menomonee Falls, WI 53052-0309
Phone 1-800-BRADLEY FAX 262-251-5817
<http://www.bradleycorp.com>
Technical Information Fax Service: 1-800-BRADFAX