

Diverter Shower Valves

How they Work:

Clockwise rotation of the handle and stem causes the stem and washers (Item 3) to move in the casting and divert the water flow to the shower head. Counter-clockwise rotation of the handle caused the water flow to be diverted to the shower hose.

Troubleshooting		
<i>Problem ----- Cause ----- Solution</i>		
Water drips from handle or bonnet	O-Ring worn or bonnet insufficiently tightened	Replace O-Ring or tighten bonnet
Water will not divert	Washers (Item 3) worked loose from seat resulting in washer not seating properly	Replace washers