

215-1447 Rev. J; ECN 17-00-014 © 2017 Bradley Page 1 of 26 9/28/2017 Parts & Service

**Terreon Multi-Fount Washfountain** 

Current Models After February 1, 2013

**MF2922** Corner-Fount<sup>™</sup>

### **MF2933** Tri-Fount<sup>™</sup>

**MF2939** Tri-Fount, Wall-Hung

**MF2944** Quadra-Fount<sup>™</sup>


**MF2949** Quadra-Fount<sup>™</sup>, Wall-Hung

# Table of Contents

Infrared (IR) Air Metering (AST4) AST4 and IR Supply and Mixing Valve Battery Infrared (BIR3) TouchTime (TT) Thermostatic Mixing Valve Troubleshooting Soap System Drain Spud and Strainer Floor Pedestal Assembly Wall Mount Pedestal Assembly Sprayhead Covers Pedestal Panels Bowl Assembly	
Bowl Assembly Terreon <sup>®</sup> Cleaning and Maintenance	

Part numbers are subject to change without formal notice.






# Parts List — Infrared Sensor and Sprayhead Assembly

lterr	Devit No.	Description	Corner	Tri	Quad
Item Part No	Part No.	Description	Qty.	Qty.	Qty.
1	269-1608	Sensor - Adaptive	2	3	4
-	P10-569	Hook and Loop Fastener Strip (sensor mounting)	2	3	4
2	269-1190	Window	4	6	8
3	115-131	Sprayhead	2	3	4
4	176-119	Threaded Rod	4	6	8
5	140-748	Backplate	2	3	4
6	161-026	Nut	4	6	8
7	142-002BS	Lockwasher	4	6	8
8	269-871	Fitting Straight (front sprayhead)	-	1	2
9	269-628	Fitting Swivel 90° (side sprayheads)	2	2	2
10	R68-60011-R	Tubing 1/4", Red	*	*	*
10	R68-600011-G	Tubing 1/4", Green	*	*	*
10	R68-600011-B	Tubing 1/4", Black	*	*	*
10	R68-600011-Y	Tubing 1/4", Yellow	*	*	*


\* Specify length in feet



## Parts List — Solenoid Valve Assembly and Valve Parts

ltons	Davit No.	Description	Corner	Tri	Quad
Item	Part No.	Description	Qty.	Qty.	Qty.
1	S45-2492	IR TMA Dual valve Assembly (includes items 7-13)	1	-	-
2	S45-2493	IR TL Dual Valve Assembly (includes items 8-14)	1	-	-
3	S45-2496	IR TMA Tri Valve Assembly (includes items 7-13)	-	1	-
4	S45-2497	IR TL Tri Valve Assembly (includes items 8-14)	-	1	-
5	S45-2517	IR TMA Quad Valve Assembly (includes items 7-13)	-	-	1
6	S45-2518	IR TL Quad Valve Assembly (includes items 8-14)	-	-	1
7	S01-526	Navigator Valve, 4 GP	1	1	1
8	140-928	Bracket, Ganged Valve	1	1	1
9	P18-054	Screw 10-24 x 3/8 PN	2	2	2
10	S07-068A	Solenoid Valve, 24 VAC, through	1	2	3
11	S07-068	Solenoid Valve, 24 VAC, closed	1	1	1
12	110-231	Compression Nut, 1/4"	2	3	4
13	160-447	Screw 8-16 x 5/8 PN	2	3	4
14	S39-804	Adapter, Valve Inlet	1	1	1
15	S83-152	Transformer	1	1	1

# Infrared (IR) Valve Assembly - Solenoid Valve S07-068S (Closed Body) and S07-068AS (Thru Body)




Item	Part No.	Description	Qty
1	118-307	Valve Body, 1/4" Closed	1
1	118-307A	Valve Body, 1/4", Through	1
2	269-983	Diaphragm	1
3	269-577	Armature	1
4	269-578	Spring	1
5	269-1729	Armature Housing	1
6	269-1730	clamp, Armature Housing	1
7	269-579	Coil, Solenoid Valve	1
8	160-447	Screw #8 x 5/8	3
9	125-165	O-Ring, #2-013	
10	125-160 Flow Restrictor, 0.5 GPM		1
11	S65-113	Repair Kit	1

Turn off water supplies to unit before troubleshooting.

Problem	Cause	Solution
An individual	There is debris	Remove debris between diaphragm and the valve seat.
		<ol> <li>Remove the three #8 Phillips-head screws that hold the solenoid valve assembly together. Be careful not to lose the armature or spring (see previous page).</li> </ol>
unps.		2. Remove the diaphragm. Remove any particles that have been trapped between the diaphragm and the valve seat. Rinse off the diaphragm and inspect for damage. Make sure the center orifice and both small side orifices are open.
		<ol> <li>Reassemble in reverse order, being careful not to overtighten the Phillips-head screws or you may crack the plastic valve body. Tighten until the armature plate makes contact with the plastic body.</li> </ol>
		4. Reconnect the wiring per diagram.
An individual	A failed coil for	Test the station to determine cause.
operating station fails to turn on.	the valve or loose electrical	1. Disconnect the wires from the coil of an adjacent valve. Disconnect the wires from the problem valve and reconnect to the adjacent valve.
	connection to the terminal.	<ol><li>Turn on electrical and water supplies to the unit. Place hands in front of sensor for the problem station; the adjacent station should turn on.</li></ol>
		If the adjacent station turns on and cycles normally, replace the coil on the problem valve.
		If the adjacent valve fails to turn on, inspect the wires from the sensor cable and do the following:
		<ul> <li>make sure there are no breaks and that the fully insulated disconnect terminals are firmly crimped in place;</li> </ul>
		<ul> <li>turn off the electrical and water supplies;</li> </ul>
		<ul> <li>reconnect to the adjacent valve and turn on the water supplies to the unit;</li> </ul>
		<ul> <li>place hands in front of sensor. If the station still fails to turn on, replace the sensor.</li> </ul>


V



# Parts List — AST4 Pushbutton and Sprayhead


Item Part No.	Part No.	Part No. Description	Corner	Tri	Quad
nem	Part No.	Description	Qty.	Qty.	Qty.
1	S08-340	Pushbutton Assembly (Includes Items 2 thru 4)	2	3	4
2	128-090	Pushbutton Only	2	3	4
3	179-104	Guide for Pushbutton	2	3	4
4	147-034	Shoulder Screw for Pushbutton	2	3	4
5	182-110	Spacer	2	3	4
6	140-743	Brackey	2	3	4
7	110-115	Nut	2	3	4
-	S65-168	Actuator Assembly (Includes Items 9 thru 14)	2	1	2
-	S65-168A	Actuator Assembly (Includes Items 9 thru 15)	-	2	2
9	119-227A	Piston	2	3	4
10	125-099	U-Cup	2	3	4
11	135-065	Spring	2	3	4
12	118-279	Actuator Body	2	3	4
13	198-010	Duckbill Check	2	3	4
14	169-890	Tube Connector 1/8" Straight	2	3	4
15	269-1186	Fitting Adj J	-	2	2
16	160-165	Screw	4	6	8
17	R68-600008-R	Tubing 1/8" OD, Red	*	*	*
17	R68-600008-G	Tubing 1/8" OD, Green	*	*	*
17	R68-600008-B	Tubing 1/8" OD, Black	*	*	*
17	R68-600008-Y	Tubing 1/8" OD, Yellow	*	*	*
18	115-131	Sprayhead	2	3	4
19	176-119	Threaded Rod	4	6	8
20	269-1190	Window Hole Plug	4	6	8
21	140-748	Backplate	2	3	4
22	161-026	Nut	4	6	8
23	142-002BS	Lockwasher	4	6	8
24	269-871	Fitting Straight (Front Sprayhead)	-	1	2
25	269-628	Fitting Swivel 90° (Side Sprayheads)	2	2	2
26	R68-600011-R	Tubing 1/4" ID, Red	*	*	*
26	R68-600011-G	Tubing 1/4" ID, Green	*	*	*
26	R68-600011-B	Tubing 1/4" ID, Black	*	*	*
26	R68-600011-Y	Tubing 1/4" ID, Yellow	*	*	*
27	130-023	Spanner Wrench	1	1	1

\* Specify length in feet.




## Parts List — Air Metering Valve Assembly


ltown	Dout No.	Description	Corner	Tri	Quad
Item	Item Part No.	Description	Qty.	Qty.	Qty.
1	S08-1452TMA	TMA Dual Valve Assembly (Includes Items 7 thru 13)	1	-	-
2	S08-1452TL	TL Dual Valve Assembly (Includes Items 8 thru 14)	1	-	-
3	S08-1453TMA	TMA Tri Valve Assembly (Includes Items 7 thru 13)	-	1	-
4	S08-1453TL	TL Tri Valve Assembly (Includes Items 8 thru 14)	-	1	-
5	S08-1454TMA	TMA Quad Valve Assembly (Includes Items 7 thru 13)	-	-	1
6	S08-1454TL	TL Quad Valve Assembly (Includes Items 8 thru 14)	-	-	1
7	S01-526	Navigator Valve, 4 GP	1	1	1
8	140-928	Bracket, Ganged Valve	1	1	1
9	P18-054	Screw 10-24 x 3/8 PN	2	2	2
10	S07-078AS	AST4 Valve, Through	1	2	3
11	S07-078S	AST4 Valve, Closed	1	1	1
12	110-231	Compression Nut, 1/4"	2	3	4
13	160-447	Screw 8-16 x 5/8 PN	2	3	4
14	S39-804	Adapter, Valve Inlet	1	1	1



# Parts List — AST4 Valve Repair Kits

Item	Part No.	Description
1	125-165	O-Ring
2	118-307A	Valve Body - Manifolded
3	118-307	Valve Body - Closed
4	269-983	Diaphragm
5	269-577	Armature, Valve
6	269-578	Spring, Valve
7	7 118-309 Cover, AST4 Valve	
8	107-538	Cover, AST4 Valve Timer
9	S27-305	Timer, ASM, AST4 Valve
10	125-001BY	O-Ring
11	110-234	Compression Nut, 1/8"
12	S39-591	Magnet/Diaphragm Assembly
13	107-535	Cover, AST4 Valve
14	110-233	Clamp Nut, AST4 Valve
15	160-449	Screw 8-16 x 7/8"
16	S65-261	Repair Kit - AST4 Valve - Upper
17	S65-262	Repair Kit - AST4 Valve - Lower
18	S65-260	Repair Kit - AST4 Valve - Complete





# **Supply Parts List**

			Corner	Tri	Quad
Item	Part No.	Description	Qty	Qty	Qty
1*	269-2053	Flex Hose (Supply to TMV)	2	2	2
2*	S27-340	Stop	2	2	2
3	160-169	Screw	2	2	2
* 1.100	Oty 1 for	El option all models			


\* Use Qty 1 for TL option, all models.

# Battery Infrared (BIR3) - Sprayhead

# Parts List - Battery Infrared Sensor and Sprayhead

			Corner	Tri	Quad
Item	Part No.	Description	Qty	Qty	Qty
1	251-019A	Sensor Eye Leads	2	3	4
2	269-1190	Window	4	6	8
3	115-131	Sprayhead	2	3	4
4	176-119	Threaded Rod	4	6	8
5	140-748	Backplate	2	3	4
6	161-026	Nut	4	6	8
7	142-002BS	Lockwasher	4	6	8
8	269-871	Fitting Straight (front sprayhead)	-	1	2
9	269-628	Fitting Swivel 90° (side sprayheads)	2	2	2
10	R68-60001-R	Tubing 1/4", Red	*	*	*
10	R68-60001-G	Tubing 1/4", Green	*	*	*
10	R68-60001-B	Tubing 1/4", Black	*	*	*
10	R68-60001-Y	Tubing 1/4", Yellow	*	*	*


\* Specify length in feet.




# Parts List - Battery Infrared Valve Assembly

			Corner	Tri	Quad
Item	Part No.	Description	Qty	Qty	Qty
1	S08-1432TMA	TMA Dual Valve Assembly (includes items 7-13)	1	-	-
2	S08-1432TL	TL Fual Valve Assembly (includes items 8-14)	1	-	-
3	S08-1433TMA	TMA Tri Valve Assembly (includes items 7-13)	-	1	-
4	S08-1433TL	TL Tri Valve Assembly (includes items 8-14)	-	1	-
5	S08-1434TMA	TMA Quad Valve Assembly (includes items 7-13)	-	-	1
6	S08-1434TL	TL Quad Valve Assembly (includes items 8-14)	-	-	1
7	S01-526	Navigator Valve, 4GP	1	1	1
8	140-928	Bracket, Ganged Valve	1	1	1
9	P18-054	Screw 10-24 x 3/8 PN	2	2	2
10	S07-083AS	BIR3 Valve, through (includes items 16-17)	1	2	3
11	S07-083S	BIR3 Valve, closed (includes 16-17)	1	1	1
12	110-231	Compression Nut, 1/4"	2	3	4
13	160-447	Screw 8-16 x 5/8" PN	2	3	4
14	S39-804	Adapter, Valve Inlet	1	1	1
16	S83-178	Circuit Board	2	3	4
17	160-451	Screw #6-19 x 3/4	2	3	4
18	S83-177	Battery Holder	2	3	4
19	261-010	Lithium Battery, Type DL223A or Equivalent	2	3	4
20	S45-2083	Battery Prepack (includes items 18-19)	2	3	4

# Battery Infrared Valve (BIR3) Assembly - Solenoid Valve S07-073S (Closed Body) and S07-073AS (Thru Body)



Item	Qty	Part No.	Description
1	1	118-307	Valve Body, 1/4" Closed
1	1	118-307A	Valve Body, 1/4" Thru
2	1	269-983	Diaphragm
3	1	192-017	Armature
4	1	136-093	Spring
5	1	269-1729	Armature Housing
6	1	269-1730	Clamp, Armature Housing
7	1	269-1731	Coil, Solenoid Valve
8	3	160-447	SCrew, #8 x 5/8"
9	1	125-165	O-Ring, #2-013
10	1	125-160	Flow Restrictor, .5 GPM



# **Troubleshooting BIR3 Components**

CAUTION: Turn off water supplies to unit before troubleshooting.

Problem: An individual operating station drips and fails to shut off.

Cause: There is debris trapped between the diaphragm and the valve seat.

#### Solution: Remove debris between diaphragm and the valve seat.

Disconnect the plug from the battery to the circuit board of the problem valve. Remove the three #8 Phillips-head screws that hold the solenoid valve assembly together. Be careful not to lose the armature or spring. Remove the diaphragm. Remove any particles that are trapped between the diaphragm and the valve seat. Rinse off the diaphragm and inspect for damage. Make sure the center orifice and both small side orifices are open. Reassemble in reverse order, being careful not to overtighten the Phillips-head screws or you may crack the plastic valve body. Tighten until the armature plate makes contact with the plastic body. Reconnect the battery plug. Turn on water supplies to the unit.

#### Problem: An individual operating station fails to turn on or off.

Cause: Excessive line pressure.

Solution: Install pressure reducing valve.

Check the static line pressure. If the pressure exceeds 80 psi, install a pressure reducer valve at the street main. Excessive line pressure (over 60 psi) will shorten the life of any valve.

Problem: An individual operating station fails to turn on or off.

Cause: A dead or faulty battery.

#### Solution: Test the station to determine cause and replace battery if required.

Disconnect the plug from the battery to the circuit board of the problem valve. Disconnect the plug from the battery to the circuit board of an adjacent valve. Connect the battery plug from the adjacent working valve to the problem valve. Wait for ten seconds. Activate the problem station's sensor ten times. The station should turn on. If the station turns on, and cycles normally, replace the battery.

#### Cause: Faulty sensor eyes.

#### Solution: Test station to determine cause; replace sensor eyes if required.

Disconnect the sensor cable from the circuit board of the problem valve. Disconnect the sensor cable from the circuit board of an adjacent working valve. Connect the sensor cable from the adjacent working valve to the problem valve. Activate the problem station's sensor. The station should turn on. If the station turns on and cycles normally, replace the sensor eyes.


#### Cause: Faulty solenoid valve.


#### Solution: Test station to determine cause; replace solenoid valve if required.


Remove the screw, circuit board and standoff from the problem valve. Remove the battery holder. With a good working battery, briefly contact the solenoid valve directly with the battery as shown in Open Valve figure to right. The contact should cause the valve to open. With the battery holder removed, briefly contact the solenoid valve with the battery in the position shown in Closed Valve figure to right. This should cause the valve to close. If the valve does not operate when directly contacted with a good battery, and the solenoid valve has already been cleaned as outlined at the beginning of this troubleshooting section, replace the solenoid valve.

#### If problems persist:

Pass your hand in front of the problem station, while at the same time looking to see if the indicator light on the circuit board flashes (the indicator light is located near the hole in the circuit board where the standoff is mounted). If it does not flash, and the battery and sensor eyes have already been tested as outlined above, the problem may be with the circuit board. Make a note of the numbers printed on the circuit board, then contact your Bradley representative for assistance.








# Parts List - TouchTime (Switch and Sprayhead)

			Corner	Tri	Quad
Item	Part No.	Description	Qty	Qty	Qty
1	S83-139B	Switch TouchTime	2	3	4
2	269-1190	Window	4	6	8
3	115-131	Sprayhead	2	3	4
4	176-119	Threaded Rod	4	6	8
5	140-748	Backplate	2	3	4
6	161-026	Nut	4	6	8
7	142-002BS	Lockwasher	4	6	8
8	269-871	Fitting Straight (front sprayhead)	-	1	2
9	269-628	Fitting Swivel 90° (side sprayheads)	2	2	2
10	R68-600011-R	Tubing 1/4", Red	*	*	*
10	R68-600011-G	Tubing 1/4", Green	*	*	*
10	R68-600011-B	Tubing 1/4", Black	*	*	*
10	R68-600011-Y	Tubing 1/4", Yellow	*	*	*
11	182-115	Spacer	2	3	4
12	110-115	Nut, 1/2-14	2	3	4
13	130-023	Spanner Wrench	1	1	1
* Spec	Specify length in feet.				


Specify length in feet.



# Parts List - TouchTime Metering Valve Assembly

			Corner	Tri	Quad
Item	Part No.	Description	Qty	Qty	Qty
1	S45-2494	TT TMA Dual Valve Assembly (Transformer not Included)	1	-	-
2	S45-2495	TT TL Dual Valve Assembly (Transformer not Included)	1	-	-
3	S45-2498	TT TMA Tri Valve Assembly (Transformer not Included)	-	1	-
4	S45-2499	TT TL Tri Valve Assembly (Transformer not Included)	-	1	-
5	S45-2519	TT TMA Quad Valve Assembly (Transformer not Included)	-	-	1
6	S45-2520	TT TL Quad Valve Assembly (Transformer not Included)	-	-	1
7	S01-526	Navigator Valve, 4GP	1	1	1
8	140-928	Bracket, Ganged Valve	1	1	1
9	P18-054	Screw 10-24 x 3/8 PN	2	2	2
10	S07-068A	Solenoid Valve, 24 VAC, through	1	2	3
11	S07-068	Solenoid Valve, 24 VAC, closed	1	1	1
12	110-231	Compression Nut, 1/4"	2	3	4
13	160-447	Screw 8-16 x 5/8 PN	2	3	4
14	S39-804	Adapter, Valve Inlet	1	1	1
15	S83-134	Transformer	1	1	1

# TouchTime Valve (TT) Assembly - Solenoid Valve S07-068S (closed body) and S07-068AS (thru body)



Item	Qty.	Part No.	Description
1	1	118-307	Valve Body, 1/4" Closed
1	1	118-307A	Valve Body, 1/4" Thru
2	1	269-983	Diaphragm
3	1	269-577	Armature
4	1	269-578	Spring
5	1	269-1729	Armature Housing
6	1	269-1730	Clamp, Armature Housing
7	1	269-579	Coil, Solenoid Valve
8	3	160-447	Screw, #8 x 5/8
9	1	125-001CS	O-Ring, #2-013
10	1	125-160	Flow Restrictor, .5 GPM
11	1	S65-113	Repair Kit

Problem	Cause	Solution	
An individual	Debris is	Remove debris between diaphragm and the valve seat.	
operating station fails to shut off	trapped between the diaphragm	1. Remove the three #8 Phillips-head screws that hold the solenoid valve assembly together. Be careful not to lose the armature or spring.	
and drips.	and the valve seat.	<ol><li>Remove the diaphragm. Remove any particles that have been trapped between the diaphragm and the valve seat. Rinse off the diaphragm and inspect for damage. Make sure the center orifice and both small side orifices are open.</li></ol>	
		3. Reassemble in reverse order (do not overtighten the Phillips-head screws or the plastic valve body may crack). Tighten until the armature plate makes contact with the plastic body.	
		4. Reconnect the wiring.	
An individual	A failed coil for	Test the station to determine the cause.	
operating station fails to turn on.	the valve or loose electrical connection to	<ol> <li>Disconnect the wires from the coil of an adjacent valve. Disconnect the wires from the problem valve and reconnect to the adjacent valve.</li> </ol>	
	the terminal.	2. Turn on electrical and water supplies to the unit. Pass your hand in front of the sensor of the problem station, and the adjacent station should turn on.	
		If the adjacent station turns on and cycles normally, replace the coil on the problem valve.	
		If the adjacent valve fails to turn on, inspect the wires from the sensor cable and do the following:	
		<ul> <li>make sure there are no breaks and that the fully insulated disconnect terminals are firmly crimped in place;</li> </ul>	
		<ul> <li>turn off the electrical and water supplies;</li> </ul>	
		<ul> <li>reconnect to the adjacent valve and turn on the water supplies to the unit;</li> </ul>	
		<ul> <li>pass your hand in front of the sensor. If the station still fails to turn on, replace the sensor.</li> </ul>	

# **Thermostatic Mixing Valve Troubleshooting**


Before attempting to troubleshoot the valve or disassemble the components, check for the following conditions:

- If stop valves are used, make sure that they are fully open.
- Make sure that the hot and cold inlet pipes are connected properly, and that there are no cross-connections or leaking stop valves.
- Check the hot water heater output to make sure that it is at least 10° F above the set temperature.



Be sure to close the appropriate shut-off valves prior to disassembly of the valve and reopen the valves after inspection and repair is complete.


Problem	Cause	Solution
External leaks.	Damaged cartridge or O-rings.	Replace cartridge with part number 269-1927
Improper water temperature or	Hot water supply is not 10° above desired set point.	Increase hot water supply temperature
temperature fluctuation.	Valve temperature is not properly set.	Adjust the temperature.
nucluation.		1. Loosen the cap screw about 1/4" (4-6 turns) and lift up the cover (do not remove).
		2. Using the cover, turn the cartridge gently until desired water temperature is reached. Do not turn past stops as this may damage the unit. Push the cover down and tighten the screw.
Limited water flow.	Dirt and debris have built up in the valve or strainer.	3. Check to make sure both hot and cold supplies are connected to the Navigator mixing valve and that they have water flow.
		4. Remove cover and U-clip. Remove the cartridge and clean the strainer. It is not required to grease cartridge, however if desired, use silicone grease only. Do not use grease on check valves.



# Parts List

Item	Part No.	Description	Quantity
nem	Part NO.	Description	S59-4000
1	160-463	Cap Screw	1
2	107-582	Cover	1
3	269-1927	Thermostatic Cartridge	1
4	198-014	Check Valve*	2
5	132-051	Retaining Ring*	2
6	118-319	Valve Body	1
7	146-079	U-Clip	1


\* Included with Prepack S65-326




# Soap System

## Parts List - Soap Valve S09-083

Item	Part No.	Description	Qty
	S09-083	Soap Valve Complete	1
1	S64-096	Plunger Assembly	1
2	110-227A	Collar	1
3	160-239	Set Screw	1
4	125-168	O-Ring	1
5	198-013	Seat Assembly	2
6	135-097	Spring	1
7	144-068M	Cylinder	1
8	R68-800002	Tube 3/8" ID (Specify Length in Feet)	1



Item	Part No.	Description	Qty
1	240-001	Soap Tank	1
2	169-989	Hose 5/8 ID	*
3	146-040	Hose Clamp	1
4	169-916	Male Fitting	1
5	110-093	Nut	1
6	140-002CJ	Washer	1
7	153-174	Filler	1
8	136-011	Soap Filler Cap	1
9	R68-60021	Tube Vent 3/16	*
10	136-049	Soap Tank Cap	1
11	269-1832	Bulkhead Fitting	1
12	R68-00002	Tube Supply 1/2	*
13	269-1833	Тее	1
14	110-115	Nut	2
15	142-002CB	Washer	2
16	S52-109	Soap Valve Body Assembly	2
17	S09-083	Soap Valve	2
18	130-142	Soap Filler Cap Wrench	1
19	161-026	Nut	2
20	142-002AV	Washer	2
21	269-1834	Ferrule	1
22	R68-600012	Tube	*
23	S50-409	Complete Soap System (incl. items 1-22)	1



# Soap System

## **Soap Recommendations**

Quality soap dispensers require good quality soap and periodic maintenance to properly operate. Bradley soap dispensers will provide dependable, consistent operation over the long term when soap with reasonable viscosity and pH levels are used and when a minimal amount of periodic maintenance is performed on the valves.

Soap thickness is determined by a measurement called viscosity. Soap viscosity should be between 100 cps (centerpoise) and 2500 cps for all Bradley soap dispensers. Thinner soaps are perceived by the users as being "watered down" so users tend to take more than they need, resulting in waste. **Thick soaps flow slower and inhibit the "flushing" action of the valves, which allows the soap to congeal in the valve and cause clogs.** 

The pH (acid) level of the soap should be in the range of 6.5 to 8.5. More acidic soaps (pH levels lower than 6.5) will corrode metal parts (even stainless steel!!) and degrade rubber and plastic components. They will also cause skin irritation. **Most inexpensive soaps (typically the pink lotion type) fall into this acidic category and will eventually cause valve failure and metal corrosion.** Base soaps (pH levels higher than 8.5) will cause swelling or degradation of rubber and plastic parts and skin irritation.

Generally, any quality soap meeting the viscosity and pH guidelines above will work well with Bradley soap dispensers. PCMX or Isapropanol based antibacterial soaps (within viscosity and pH limits) will also work with Bradley dispensers. Soaps satisfying these basic guidelines will provide consistent flow and reduce clogs.

Most soap dispenser problems are caused by soap that is too thick or corrosive, or by a lack of maintenance. Many soaps come in concentrate form which must be diluted with water. Often, the soap is improperly diluted or used straight out of the bottle, which causes clogging and valve failure. If proper soap is being used, valves that have never been cleaned are usually the source of dispensing problems. Bradley has entered into an agreement with Champion Brand Products to provide additional customer service for purchasers of our dispensers regarding soap issues. They are very helpful and can get to the bottom of almost any soap dispenser related problem. They also sell an excellent "Bradley approved" soap. Please see **Soap Instruction Sheet 215-1286** for details about soap valve cleaning or how to contact Champion. With proper maintenance and soap, Bradley dispensers will provide long term, trouble free operation.


# Soap Dispenser Maintenance Instructions for Multi-Fount Washfountains

Bradley soap dispensers will provide dependable, consistent operation over the long term when the proper soap is used and when a minimal amount of periodic maintenance is performed on the valves. Valves must be maintained (cleaned) to function properly.

To ensure proper operation of your soap dispenser, follow these instructions:

- Once per month, remove the cap from the soap tank and insert the draw tube (below the cap) into hot water and soak it for 30 minutes.
- Push valve at least 20 times while it is soaking.
- Flush soap reservoir with hot water while valve is soaking.

In cases of extreme clogging, the valve should be disassembled and the parts should be soaked in hot water or cleaning solution to restore proper functioning. Soap dispensers that will not be used for extended periods of time (schools during summer break, etc.) should be drained, cleaned and left empty until put back into service. Soap left on the outside of dispensers can cause discoloration and corrosion of the reservoir (even on stainless steel units). All soap should be wiped or scrubbed off daily, then the outside of the dispenser should be rinsed with clear water and dried with a soft cloth.



4

1

1

1

-

\_

1

1

4

1

1

1

-

-

1

1

4

1

-

-

1

1

1

1

Access panel (Item 7) part numbers include the screw and washer.

Access Panel - Standard Height

Access Panel - Standard Height

Access Panel - Juvenile Height

Access Panel - Juvenile Height

\*\* Upper Bracket Assembly includes Item 6.

Washer

Screw

142-002BJ Washer

Clip

146-055

S04-100

S04-095

S04-101

S04-096

132-031

147-019

5

6

7

7

7

7

\*8

\*9

3)

2

(7

(5)

4

6


# Wall Mount Pedestal - Assembly


			Corner	Tri	Quad
Item	Part No.	Description	Qty	Qty	Qty
1	S17-237	Pedestal Assembly	-		-
1	S17-280	Pedestal Assembly	-	-	1
*2	160-169	Screw 1/4-20	-	6	6
*3	P10-311	Screw 10-32	-	1	1
*4	146-055	C;o[	-	1	1
5	S04-102	Access Panel - Standard Height	-	1	-
**6	147-019	Screw	-	1	1
**7	132-031	Washer	-	1	1

\* Pedestal assembly (item 1) part numbers include the screws and clip

\*\* Access panel (item 5) part numbers include the screw and washer

# **Sprayhead Cover Attaching Hardware**





# 6 2 3 Quadra-Fount

# Corner-Fount

## Parts List - Sprayhead Cover Attaching Hardware

			Corner	Tri	Quad
Item	Part No.	Description	Qty	Qty	Qty
1	159-367	Anchor Bar	-	1	-
2	330-144	Threaded Rod 1/4-20 x 11"	2	2	2
3	161-076	Wing Nut 1/4-20	2	2	2
4	113-907	Guide Tube	2	-	-
5	113-966	Support Tube	1	-	-
6	159-377	Anchor Bar	-	-	1

# **Sprayhead Covers - Replacement Parts**

# Parts Numbers - MF2922 Corner Fount

Color	Covers
Arctic Chip	S04-106AD
Bluesky	S04-106AL
Charcoal	S04-106K
Cobblestone	S04-106T
Coffee Bean	S04-106AJ
Cornfield	S04-106AK
Empire Gray	S04-106
Graphite	S04-106P
Hillside	S04-106AM
Jade	S04-106N

Color	Covers
Lannonstone	S04-106S
Landon Gray	S04-106AP
Mountain Top	S04-106AN
Mystic Moss	S04-106AG
Organic Taupe	S04-106AR
Peppered White	S04-106E
Riverstone	S04-106AF
Stardust	S04-106AH
Summer Sage	S04-106AE
White Sand	S04-106W

Contact Bradley for bowl part numbers.

# Parts Numbers - MF2933, MF2939 Tri-Fount

Color	Covers
Arctic Chip	S04-104AD
Bluesky	S04-104AL
Charcoal	S04-104K
Cobblestone	S04-104T
Coffee Bean	S04-104AJ
Cornfield	S04-104AK
Empire Gray	S04-104
Graphite	S04-104P
Hillside	S04-104AM
Jade	S04-104N

Color	Covers
Lannonstone	S04-104S
Landon Gray	S04-104AP
Mountain Top	S04-104AN
Mystic Moss	S04-104AG
Organic Taupe	S04-104AR
Peppered White	S04-104E
Riverstone	S04-104AF
Stardust	S04-104AH
Summer Sage	S04-104AE
White Sand	S04-104W

## Parts Numbers - MF2944, MF2949 Quadra-Fount


Color	Covers	
Arctic Chip	S04-105AD	
Bluesky	S04-105AL	
Charcoal	S04-105K	
Cobblestone	S04-105T	
Coffee Bean	S04-105AJ	
Cornfield	S04-105AK	
Empire Gray	S04-105	
Graphite	S04-105P	
Hillside	S04-105AM	
Jade	S04-105N	


Color	Covers
Lannonstone	S04-105S
Landon Gray	S04-105AP
Mountain Top	S04-105AN
Mystic Moss	S04-105AG
Organic Taupe	S04-105AR
Peppered White	S04-105E
Riverstone	S04-105AF
Stardust	S04-105AH
Summer Sage	S04-105AE
White Sand	S04-105W

# **Pedestal Panels**

# Parts List - Sprayhead Cover Attaching Hardware

	opiajiida		g	i la		
Color	Wall Mounted Left Panel	Wall Mounted Right Panel	Juvenile Height Left Panel	Juvenile Height Right Panel	Standard Height Left Panel	Standard Height Right Panel
Arctic Chip	S15-123AD	S15-124AD	S15-121AD	S15-122AD	S15-119AD	S15-120AD
Bluesky	S15-123AL	S15-124AL	S15-121AL	S15-122AL	S15-119AL	S15-120AL
Charcoal	S15-123K	S15-124K	S15-121K	S15-122K	S15-119K	S15-120K
Cobblestone	S15-123T	S15-124T	S15-121T	S15-122T	S15-119T	S15-120T
Coffee Bean	S15-123AJ	S15-124AJ	S15-121AJ	S15-122AJ	S15-119AJ	S15-120AJ
Cornfield	S15-123AK	S15-124AK	S15-121AK	S15-122AK	S15-119AK	S15-120AK
Empire Gray	S15-123	S15-124	S15-121	S15-122	S15-119	S15-120
Graphite	S15-123P	S15-124P	S15-121P	S15-122P	S15-119P	S15-120P
Hillside	S15-123AM	S15-124AM	S15-121AM	S15-122AM	S15-119AM	S15-120AM
Jade	S15-123N	S15-124N	S15-121N	S15-122N	S15-119N	S15-120N
Lannonstone	S15-123S	S15-124S	S15-121S	S15-122S	S15-119S	S15-120S
London Gray	S15-123AP	S15-124AP	S15-121AP	S15-122AP	S15-119AP	S15-120AP
Mountaintop	S15-123AN	S15-124AN	S15-121AN	S15-122AN	S15-119AN	S15-120AN
Mystic Moss	S15-123AG	S15-124AG	S15-121AG	S15-122AG	S15-119AG	S15-120AG
Organic Taupe	S15-123AR	S15-124AR	S15-121AR	S15-122AR	S15-119AR	S15-120AR
Peppered White	S15-123E	S15-124AE	S15-121E	S15-122E	S15-119E	S15-120E
Riverstone	S15-123AF	S15-124AF	S15-121AF	S15-122AF	S15-119AF	S15-120AF
Stardust	S15-123AH	S15-124AH	S15-121AH	S15-122AH	S15-119AH	S15-120AH
Summer Sage	S15-123AE	S15-124AE	S15-121AE	S15-122AE	S15-119AE	S15-120AE
White Sand	S15-123W	S15-124W	S15-121W	S15-122W	S15-119W	S15-120W





# Parts List - Bowl Assembly

			Corner	Tri	Quad
Item	Part No.	Description	Qty	Qty	Qty
1	160-301	Bolt	2	2	2
2	142-002CG	Washer	2	2	2
3	140-260	Bracket	2	2	2
4	200-015	Plate	2	2	2
5	142-002CH	Lockwasher	2	2	2
6	161-065	Nut	2	2	2

# **Terreon® Cleaning and Maintenance**

**Material Description:** Terreon is an NAHB Certified densified solid surface material composed of polyester resin and is resistant to chemicals, stains, burns and impact. Surface damage can be easily repaired with everyday cleansers or fine grit abrasives.

**Routine Cleaning:** Clean daily or as often as conditions require using a standard commercial or household cleaner such as Formula 409<sup>®</sup> or Windex<sup>®</sup>.

**Stubborn Stains:** Remove tough stains with Ajax<sup>®</sup>, Comet<sup>®</sup>, or Soft-Scrub<sup>®</sup> and a green Scotch-Brite<sup>®</sup> pad or lightly sand in a circular motion with 240 grit wet/dry sandpaper. The finish can be renewed with a maroon Scotch-Brite pad.

## **Special Situations for Material**

Scratches: Remove scratches with a green Scotch-Brite® pad. The finish can then be renewed with a maroon Scotch-Brite® pad.

Hard Water Deposits: Remove hard water deposits with a mild solution of vinegar and water. Always rinse the unit thoroughly after cleaning.

**Restoring the surface:** Use Hope's<sup>®</sup> Solid Surface cleaner and polish to refresh and protect the Terreon Solid Surface material. Bradley recommends additional care and maintenance for the darker colored Terreon. For complete instructions on this additional maintenance see Bradley document #1505.

Do not use strong acid or alkaline chemicals and cleansers to clean Terreon. If these chemicals come in contact with the Terreon surface, wipe them off immediately and rinse with soapy water.

Avoid contact with harsh chemicals such as paint remover, bleach, acetone, etc. Avoid contact with hot pans and objects.

Repair Kits: Terreon repair kits are available. Contact your Bradley representative or distributor for part numbers and pricing.



Repair kits are made to order and have a shelf life of 30 days.

**Brand Names:** Use of brand names is intended only to indicate a type of cleaner. This does not constitute an endorsement, nor does the omission of any brand name cleaner imply its inadequacy. Many products named are regional in distribution, and can be found in local supermarkets, department and hardware stores, or through your cleaning service. It is emphasized that all products should be used in strict accordance with package instructions.



When cleaning units equipped with infrared (electronic eye) activation, it is helpful to turn off the power to the unit or cover the windows to prevent accidental activation. After the window is covered, the water will run for approximately 30 seconds and then shut off.